

Read this document carefully before using this device. The guarantee will be expired by device demages if you don't attend to the directions in user manual. Also we don't accept any compensations for personal injury, material damage or capital disadvantages.

## ENDA EPCR02 CURRENT PROTECTION RELAY

Thank you for choosing **ENDA EPCR02** Rail mounted current protection relays.



- \* Low-current protection
  \* Current set value can be adjusted
- \* Start. error condition time can be adjusted
- \* Contact output for system control (OUT)
- \* Rail monted, screw-terminal connection
- \* CE marked according to European Norms

ORDER CODE EPCR02 - Current Protection Relay **C**€ R⊗HS Compliant

### **Technical Specifications**

#### OPERATING

ENDA Current protection relays are designed for in order to protecting the atached systems from overcurrent or low-current loads. Before device is turned on, timing, set and mode values must be set.

1- Overcurrent Protection: For this mode potentiometer must be on UpL position.

When device is powered, output relay status will be ON. During the first operation, system will loaded overcurrent at momentary. For this reason, in order to avoid the device from entering the error mode, start delay time activated. At the end of this period, if the measured current greater than adjusted set value, error condition activated. During this time, current value does not below the set value, output relay status will be OFF. Device restarts after 5 sec delay time but the start button must be pressed for running the system.

# 2- Low-current Protection : For this mode potentiometer must be on LoL position. When device is powered, output relay status will be ON. During the first operation, in order to avoid the device from entering the error mode, start delay time activated. At the end of this period, if the measured current lower than adjusted set value, error condition activated. During this time, current value does not upper the set value, output relay status will be OFF. Device restarts after 5 sec delay time but the start button must be pressed for running the system

CONTROL			
Start delay time (t <sub>e</sub> ) 1, 2, 6, 8, 1		1, 2, 6, 8, 10 sec,	can be selected on device.
Error delay time (te)		0.5, 1, 2, 3, 4, 5 sec, can be selected on device.	
Current set value (A)		0.5, 1, 2, 3, 4, 5 A AC can be selected on device.	
Overcurrent protection		Mode potentiometer must be on UpL position.	
Low-current protection		Mode potentiometer must be on LoL position.	
Current frequency range		45-65 Hz.	
ALARM CONDITIONS			
LEDx	LED Status		Description
PWR	ON		Device running
	OFF		Device not running
OUT	ON		Relay activated
	OFF		Relay deactivated
AL1/AL2	AL1 OFF, AL2 OFF		System running normaly (No faulty condition)
	AL1 ON, AL2 OFF		Low current
	AL1 OFF, AL2 ON		Overcurrent
	AL1 and AL2 Blinking slowly		Start delay time activated
	AL1 and AL2 Fast blink		Repeated start delay time (5 seconds) activated
While the Relay LED in ON state and If, the AL1 and/or AL2 alarm LEDs are in ON state, delay time is active. When delay time is over, out Relay and LED state turns off.			

ELECTRICAL CHARACTERISTICS Supply voltage 125-410V AC +%10 -%10 **Operating frequency** 45-65 Hz Power consumption Max. 10VA. Connection Screw-terminal connection. Reset time Max. 0.01 seconds Accuracy Depending on the effect of voltage : Max. %1 : Max. %5 Measurement error Depending on the effect of temperature : Max %1 FMC EN 61326-1: 2012 Safety requirements EN 61010-1: 2010 (pollution degree 2, overvoltage category II) Insulation test voltage 3kV AC min. 1 minute, 4,2kV DC min. 1 minute. ENVIRONMENTAL CONDITIONS Ambient/storage temperature 0 ... +50°C/-25 ... +70°C (With no condensation and icing). Max. humidity 80% for temperatures up to 31°C decreasing linearly to 50% relative Max. relative humidity humidity at 40°C. (With no condensation and icing). Rated pollution degree IP20, According to EN 60529 Height Max. 2000m Do not use the device in locations subject to corrosive and flammable gasses. OUTPUTS Control output (OUT) Relay: 250V AC, 10A (for resistive load), NO+NC Life expectancy for relay Without load 10.000.000 operation: 250V AC, 10A resistive load 50.000 operation. Control output state Out LED control output (OUT) lights up when device is powered. CONTROL Mounting Rail mounted (EN 60715, Th35) Dimensions W18xH84xD62mm Approx. 90g (after packaging) Weight Enclosure material Self extinguishing plastics. While cleaning the device, solvents (thinner, benzine, acid etc.) or corrosive materials must not be used. CONNECTION DIAGRAM





SISEL MÜHENDISLİK ELEKTRONİK SAN. VE TİC. A.Ş. Şerifali Mah. Barbaros Cad. No:18 Y.Duduliu 34775 UMRANIYE/ISTANBUL-TURKEY Tel:+90 216 499 46 64 Pbx. Fax:+90 216 365 74 01 ul::www.enda.com.ir



## **CONNECTION DIAGRAM**





ENDA EPCR02 Series current protection relays are rail mounted devices. Make sure that the device is used only for intended purpose. The shielding must be grounded on the instrument side. During an installation, all of the cables that are connected to the device must be free of energy. The device must be protected against inadmissible humidity, vibrations, severe soiling and make sure that the operation temperature is not exceeded. All input and output lines that are not connected to the close to the power cables or components. The installation and electrical connections must be carried on by a qualified staff and must be according to the relevant locally applicable regulations.

### DIMENSIONS



1) Mains supply cords shall meet the requirements of IEC

Relay status LED. (When OUT relay is turned on, OUT LED lights.)

Running mode selection. (High or Low current protection)

2) In accordance with the safety regulations, the power supply

switch shall bring the identification of the relevant instrument and it should be easily accessible by the operator.

 $\wedge$ 

Supply indicator.

Current limit selection.

ENDA

EPCR02

QW/

٥U

60227 or IEC 60245.





SISEL MÜHENDISLIK ELEKTRONIK SAN. VE TİC. A.Ş. Şerfali Mah. Barbaros Cad. No:18 V.Dudullu 34775 UMRANIYE/STANBUL-TURKEY Tel :+90 216 499 46 64 Pbx. Fax : +90 216 365 74 01 ur : www.enda.com.tr

